



Rowe to Kibblewhite Parts - Crossover List

1984-1999 Evo OEM Style Cast Iron Intake Guide

Description	ROWE P/N	KPMI P/N
Std Intake	5184-00	20-4320C
.001 OS	5184-01	20-4321C
.002 OS	5184-02	20-4322C
.003 OS	5184-03	20-4323C
.004 OS	5184-04	20-4324C
.010 OS	5184-10	20-4329C

1984-1999 Evo OEM Style Cast Iron Exhaust Guide

Description	ROWE P/N	KPMI P/N
Std Exhaust	5185-00	20-4320C
.001 OS	5185-01	20-4321C
.002 OS	5185-02	20-4322C
.003 OS	5185-03	20-4323C
.004 OS	5185-04	20-4324C
.010 OS	5185-10	20-4329C

1978-1983 80" Shovelhead Cast Iron Intake Guide

Description	ROWE P/N	KPMI P/N
Std Intake	5104-00	20-2050C
.001 OS	5104-01	20-2051C
.002 OS	5104-02	20-2052C
.003 OS	5104-03	20-2053C
.004 OS	5104-04	20-2054C
.005 OS	5104-05	20-2055C
.006 OS	5104-06	20-2056C
.008 OS	5104-08	20-2058C
.010 OS	5104-10	20-2059C
.025 OS	N/A	20-50HSC

1978-1983 80" Shovelhead Cast Iron Exhaust Guide

Description	ROWE P/N	KPMI P/N
Std Ex	5105-00	20-2060C
.001 OS	5105-01	20-2061C
.002 OS	5105-02	20-2062C
.003 OS	5105-03	20-2063C

.004 OS	5104-04	20-2064C
.005 OS	5105-05	20-2065C
.006 OS	5105-06	20-2066C
.008 OS	5105-08	20-2068C
.010 OS	5105-10	20-2069C
.025 OS	N/A	20-60HSC

1966-1977 74" Shovelhead Cast Iron Intake Guide

Description	ROWE P/N	KPMI P/N
Std Int	5131-00	20-2020C
.001 OS	5131-01	20-2021C
.002 OS	5131-02	20-2022C
.003 OS	5131-03	20-2023C
.004 OS	5131-04	20-2024C
.006 OS	5131-06	20-2026C
.008 OS	5131-08	20-2028C
.010 OS	5131-10	20-2029C
.025 OS	N/A	20-20HSC

1966-1977 74" Shovelhead Cast Iron Exhaust Guide

Description	ROWE P/N	KPMI P/N
Std Ex	5132-00	20-2030C
.001 OS	5132-01	20-2031C
.002 OS	5132-02	20-2032C
.003 OS	5132-03	20-2033C
.004 OS	5132-04	20-2034C
.006 OS	5132-06	20-2036C
.008 OS	5132-08	20-2038C
.010 OS	5132-10	20-2039C
.025 OS	N/A	20-30HSC

1957-1983 Sportster Cast Iron Intake Guide

Description	ROWE P/N	KPMI P/N
Std Int	5140-00	20-2320C
.001 OS	5140-01	20-2321C
.002 OS	5140-02	20-2322C
.010 OS	N/A	20-2329C



Rowe to Kibblewhite Parts - Crossover List

1957-1983 Sportster Cast Iron Exhaust Guide

Description	ROWE P/N	KPMI P/N
Std Ex	5141-00	20-2330C
.001 OS	5141-01	20-2331C
.002 OS	5141-02	20-2332C
.010 OS	N/A	20-2339C

1936-1947 Knucklehead Cast Iron Intake Guide

Description	ROWE P/N	KPMI P/N
Std Int	5148-00	20-4095C
.002 OS	5148-02	20-4096C
.004 OS	5148-04	20-4097C
.006 OS	5148-06	20-4098C
.008 OS	N/A	20-4099C
.025 OS	N/A	20-4100C

1936-1947 Knucklehead Cast Iron Exhaust Guide

Description	ROWE P/N	KPMI P/N
Std Ex	5149-00	20-4095C
.002 OS	5149-02	20-4096C
.004 OS	5149-04	20-4097C
.006 OS	5149-06	20-4098C
.008 OS	N/A	20-4099C
.025 OS	N/A	20-4100C

1930-1973 Flathead 45" Cast Iron Guide

Description	ROWE P/N	KPMI P/N
Std Int & Ex	5145-00	20-20750
.001 OS	5145-01	20-20751
.002 OS	5145-02	20-20752
.010 OS	N/A	20-20759

1930-1973 Flathead 74"-80" Cast Iron Guide

Description	ROWE P/N	KPMI P/N
Std Int & Ex	5180-00	20-20760
.001 OS	5180-01	20-20761
.002 OS	5180-02	20-20762
.010 OS	N/A	20-20769

2005-2010 88"-103" Evo/Twin Cam Cast Iron Intake Guide

Description	ROWE P/N	KPMI P/N
Std Int	5260-00	20-20690C
.001 OS	5260-01	20-20691C
.002 OS	5260-02	20-20692C
.010 OS	5260-10	20-20699C

2005-2010 88"-103" Evo/Twin Cam Cast Iron Exhaust Guide

Description	ROWE P/N	KPMI P/N
Std Int	5260-00	20-20700C
.001 OS	5260-01	20-20701C
.002 OS	5260-02	20-20702C
.010 OS	5260-10	20-20709C

1984-1999 Evo Nickel Bronze Intake Guide

Description	ROWE P/N	KPMI P/N
Std Int	4584-00	20-4320
.001 OS	4584-01	20-4321
.002 OS	4584-02	20-4322
.003 OS	4584-03	20-4323
.004 OS	4584-04	20-4324
.010 OS	4584-10	20-4329

1984-1999 Evo Nickel Bronze Exhaust Guide

Description	ROWE P/N	KPMI P/N
Std Ex	4584-00	20-4320
.001 OS	4584-01	20-4321
.002 OS	4584-02	20-4322
.003 OS	4584-03	20-4323
.004 OS	4584-04	20-4324
.010 OS	4584-10	20-4329



Rowe to Kibblewhite Parts - Crossover List

1978-1983 Shovelhead 80" Nickel Bronze Intake Guide

Description	ROWE P/N	KPMI P/N
Std Int	0098-00	20-2050
.001 OS	0098-01	20-2051
.002 OS	0098-02	20-2052
.004 OS	0098-04	20-2054
.006 OS	0098-06	20-2056
.025 OS	N/A	20-50HS

1978-1983 Shovelhead 80" Nickel Bronze Exhaust Guide

Description	ROWE P/N	KPMI P/N
Std Ex	0099-00	20-2060
.001 OS	0099-01	20-2061
.002 OS	0099-02	20-2062
.004 OS	0099-04	20-2064
.006 OS	0099-06	20-2066
.025 OS	N/A	20-60HS

1966-1977 Shovelhead 74" Nickel Bronze Intake Guide

Description	ROWE P/N	KPMI P/N
Std Int	4500-00	20-2020
.001 OS	4500-01	20-2021
.002 OS	4500-02	20-2022
.003 OS	4500-03	20-2023
.004 OS	4500-04	20-2024
.006 OS	4500-06	20-2026
.008 OS	4500-08	20-2028
.010 OS	4500-10	20-2029
.025 OS	N/A	20-20HS

1966-1977 Shovelhead 74" Nickel Bronze Exhaust Guide

Description	ROWE P/N	KPMI P/N
Std Ex	4501-00	20-2030
.001 OS	4501-01	20-2031
.002 OS	4501-02	20-2032
.003 OS	4501-03	20-2033

.004 OS	4501-04	20-2034
.006 OS	4501-06	20-2036
.008 OS	4501-08	20-2038
.010 OS	4501-10	20-2039
.025 OS	N/A	20-30HS

1948-1965 Panhead Nickel Bronze Intake Guide

Description	ROWE P/N	KPMI P/N
Std Int	4500-00	20-2020
.001 OS	4500-01	20-2021
.002 OS	4500-02	20-2022
.003 OS	4500-03	20-2023
.004 OS	4500-04	20-2024
.006 OS	4500-06	20-2026
.008 OS	4500-08	20-2028
.010 OS	4500-10	20-2029
.025 OS	N/A	20-20HS

1948-1965 Panhead Nickel Bronze Exhaust Guide

Description	ROWE P/N	KPMI P/N
Std Ex	4501-00	20-2030
.001 OS	4501-01	20-2031
.002 OS	4501-02	20-2032
.003 OS	4501-03	20-2033
.004 OS	4501-04	20-2034
.006 OS	4501-06	20-2036
.008 OS	4501-08	20-2038
.010 OS	4501-10	20-2039
.025 OS	N/A	20-30HS

1957-1983 Sportster Nickel Bronze Intake Guide

Description	ROWE P/N	KPMI P/N
Std Int	4511-00	20-2320
.001 OS	4511-01	20-2321
.002 OS	4511-02	20-2322
.010 OS	4511-10	20-2329



Rowe to Kibblewhite Parts - Crossover List

1957-1983 Sportster Nickel Bronze Exhaust Guide

Description	ROWE P/N	KPMI P/N
Std Ex	4512-00	20-2330
.001 OS	4512-01	20-2331
.002 OS	4512-02	20-2332
.010 OS	4512-10	20-2329

2005 V-Rod Nickel Bronze Intake Guide

Description	ROWE P/N	KPMI P/N
Std Int	4590-00	20-20330
.001 OS	4590-01	20-20331
.010 OS	4590-10	20-20339

2005 V-Rod Nickel Bronze Exhaust Guide

Description	ROWE P/N	KPMI P/N
Std Int	4590-00	20-20340
.001 OS	4590-01	20-20341
.010 OS	4590-10	20-20349

1969-1976 Honda CB 750 SOHC Nickel Bronze Intake Guide

Description	ROWE P/N	KPMI P/N
Std Int	0050-00	30-0379
.002 OS	0050-02	30-0380
.015 OS	N/A	30-4034

1969-1976 Honda CB 750 SOHC Nickel Bronze Exhaust Guide

Description	ROWE P/N	KPMI P/N
Std Int	0051-00	30-0383
.002 OS	N/A	30-0384
.015 OS	N/A	30-4035

1958-1973 Triumph 500 Twin Nickel Bronze Int & Ex Guide

Description	ROWE P/N	KPMI P/N
Std	0080-00	70-0339
.002 OS	0080-02	70-0340
.004 OS	0080-04	70-0341
.006 OS	0080-06	70-0342
.015 OS	N/A	70-4031

1963-1983 Triumph 650 / 750 Nickel Bronze Int & Ex Guide

Description	ROWE P/N	KPMI P/N
Std	0081-00	70-0331
.002 OS	0081-02	70-0332
.004 OS	0081-04	70-0333
.006 OS	0081-06	70-0334
.015 OS	N/A	70-0840
.050 OS	N/A	70-4033

1971-1976 Triumph Trident 750 Triple Nickel Bronze Int & Ex Guide

Description	ROWE P/N	KPMI P/N
Std	0082-00	70-0343
.002 OS	0082-02	70-0344
.015 OS	N/A	70-4153

1968-7193 Norton 750 Nickel Bronze Intake Guide

Description	ROWE P/N	KPMI P/N
Std Int	0060-00	50-0403
.002 OS	0060-02	50-0404
.004 OS	0060-04	50-0405
.006 OS	0060-06	50-0406

1968-1973 Norton 750 Nickel Bronze Exhaust Guide

Description	ROWE P/N	KPMI P/N
Std Ex	0061-00	50-0410
.002 OS	0061-02	50-0411
.004 OS	0061-04	50-0412
.006 OS	0061-06	50-0413

1973-1977 Norton 850 Nickel Bronze Intake Guide

Description	ROWE P/N	KPMI P/N
Std Int	0062-00	50-0648
.002 OS	0062-02	50-0649
.004 OS	0062-04	50-0650
.006 OS	0062-06	50-0651



Rowe to Kibblewhite Parts - Crossover List

1973-1977 Norton 850 Nickel Bronze Exhaust Guide

Description	ROWE P/N	KPMI P/N
Std Ex	0063-00	50-0652
.002 OS	0063-02	50-0653
.004 OS	0063-04	50-0654
.006 OS	0063-06	50-0655

V-Rod Black Diamond Stainless Steel Valve

Description	ROWE P/N	KPMI P/N
Int	716-13	20-20147
Ex	717-13	20-20152

HD Twin Cam 2005 - 107mm Black Diamond Stainless Steel Valve

Description	ROWE P/N	KPMI P/N
Std Int	706-13	20-20322
Int OS	706-23	20-20323R
Std Ex	707-13	20-20325
Ex OS	707-23	20-20326R

1999-2004 HD Twin Cam 88" Black Diamond Stainless Steel Valve

Description	ROWE P/N	KPMI P/N
Std Int	700-13	20-20055
Int OS	700-53	20-20108
Std Ex	715-13	20-20057
Int OS	N/A	20-20056

1984-1999 HD Evo Black Diamond Stainless Steel Valve

Description	ROWE P/N	KPMI P/N
Std Int	700-13	20-4171
Int OS	700-53	20-4169
Std Ex	701-13	20-4170

2004-2011 HD Evo Sportster 1200 Black Diamond Stainless Steel Valve

Description	ROWE P/N	KPMI P/N
Std Int	704-13	20-20260
OS Int	N/A	20-20262
Std Ex	705-13	20-20265

OS Ex	N/A	20-20266
-------	-----	----------

1988-2003 HD Evo Sportster 1200 Black Diamond Stainless Steel Valve

Description	ROWE P/N	KPMI P/N
Int	702-12	20-2013
Ex	703-13	20-2014

1966-1977 HD Shovelhead 74" Black Diamond Stainless Steel Valve

Description	ROWE P/N	KPMI P/N
Std Int	720-13	20-4194
OS Int	720-23	20-4256
Std Ex	721-13	20-4195
OS EX 1.780"	N/A	20-4195S
OS Ex 1.812	721-33	20-4195-1

1948-1965 HD Panhead Black Diamond Stainless Steel Valve

Description	ROWE P/N	KPMI P/N
Int	N/A	20-4257
Ex	721-13	20-4195
OS Ex 1.812	721-33	20-4195-1

HD Sportster 1970-1983 Black Diamond Stainless Steel Valve

Description	ROWE P/N	KPMI P/N
Std Int	730-13	20-4196
OS Int	730-33	20-4196-1
Std Ex	731-13	20-4197
OS Ex 1.630"	731-33	20-4197-1

HD Sportster 1957-1969 Black Diamond Stainless Steel Valve

Description	ROWE P/N	KPMI P/N
Std Int	N/A	20-4258
Std Ex 1.570"	731-13	20-4197
OS Ex 1.630"	731-33	20-4197-1



Rowe to Kibblewhite Parts - Crossover List

1936-1947 HD Knucklehead

Black Diamond Stainless Steel Valve

Description	ROWE P/N	KPMI P/N
Std Int	740-03	20-4101
OS Int	N/A	20-20414
Std Ex	741-03	20-4102

1930-1973 HD Flathead 45"

Description	ROWE P/N	KPMI P/N
Int & Ex	751-03	20-20740

1930-1973 HD UL Flathead 74"

Description	ROWE P/N	KPMI P/N
Int & Ex	761-03	20-20742
OS Int & Ex	N/A	20-20743

1930-1973 HD VL Flathead 74"

Description	ROWE P/N	KPMI P/N
Int & Ex	761-03	20-20744
OS Int & Ex	N/A	20-20745

1963-1983 Triumph 650 / 750 Black Diamond Stainless Steel Valve

Description	ROWE P/N	KPMI P/N
Std Int	790-13	70-4228
OS Int	790-23	70-4229
Std Ex	791-13	70-4230
OS Ex	791-23	70-4231

1963-1983 Triumph 650 / 750 (Raw) Untreated Valve

Description	ROWE P/N	KPMI P/N
Std Int	790-11	70-70500
OS Int	N/A	70-70501
Std Ex	791-11	70-70504
OS Ex	N/A	70-70505

1958-1973 Triumph 500

Black Diamond Stainless Steel Valve

Description	ROWE P/N	KPMI P/N
Std Int	792-13	70-4290
OS Int	N/A	70-4292
Std Ex	793-13	70-4291
OS Ex	N/A	70-4293

HD Big Twin 74"/80" Wristpin Bushing

Description	ROWE P/N	KPMI P/N
	197041	20-20570
	197042	20-20572

HD Sportster Wristpin Bushing

Description	ROWE P/N	KPMI P/N
Sold individually	197044	20-0644

HD Viton Seals

Description	ROWE P/N	KPMI P/N
Evo 7mm Stem Top Hat Style	5306	20-20601
Panhead 74"/80" Shovelhead (Pkg. of 4*)	5304	20-2016



Rowe to Kibblewhite Parts - Crossover List

HD OEM Repl. Valve Seals Evolution 5/16" Stem 0.420" Guide OD

Description	ROWE P/N	KPMI P/N
Seal	4585-09	20-20620
Seal	4585-09-25	20-20620-25
Seal	4585-09-100	20-20620-100

HD OEM Repl. Valve Seals Ironhead / Sportster Intake 5/16" Stem 0.530" Guide OD

Description	ROWE P/N	KPMI P/N
Seal	0041-09	20-20621
Seal	0041-09-25	20-20621-25
Seal	0041-09-100	20-20621-100

HD OEM Repl. Valve Seals Ironhead / Sportster Exhaust 11/32" Stem 0.530" Guide OD

Description	ROWE P/N	KPMI P/N
Seal	0043-09	20-20622
Seal	0043-09-25	20-20622-25
Seal	0043-09-100	20-20622-100

HD OEM Repl. Valve Seals Panhead / Shovelhead 74" 3/8" Stem 0.562" Guide OD

Description	ROWE P/N	KPMI P/N
Seal	4400-09	20-20623
Seal	4400-09-25	20-20623-25
Seal	4400-09-100	20-20623-100

HD OEM Repl. Valve Seals Shovelhead 80" 3/8" Stem 0.625" Guide OD

Description	ROWE P/N	KPMI P/N
Seal	0095-09	20-20624
Seal	0095-09-25	20-20624-25
Seal	0095-09-100	20-20624-100

White Tool Intake / Exhaust Ironhead / Sportster / Shovelhead 80" - 3/8" Stem *Fits 20-20621 / 20-20622 / 20-20624 Seals*

Description	ROWE P/N	KPMI P/N
Installation Tool	09-4586-20	20-20630

Black Tool Intake / Exhaust Panhead / Shovelhead 74" - 3/8" Stem *Fits 20-20623 Seal*

Description	ROWE P/N	KPMI P/N
Installation Tool	09-4587-20	20-20631

Red Tool Intake / Exhaust Evolution - 5/16" Stem *Fits 20-20620 Seal*

Description	ROWE P/N	KPMI P/N
Installation Tool	N/A	20-20632

Installation Protector Green Intake Evolution / Ironhead / Sportster - 5/16" Stem *Fits 20-20620 / 20-20621 Seals*

Description	ROWE P/N	KPMI P/N
Installation Protector	09-4590-00	20-20634

Installation Protector Clear Exhaust Ironhead / Sportster - 11/32" Stem *Fits 20-20622 Seal*

Description	ROWE P/N	KPMI P/N
Installation Protector	09-4591-00	20-20635

Installation Protector Red Panhead / Shovelhead 74" & 80" - 3/8" Stem *Fits 20-20623 / 20-20624 Seals*

Description	ROWE P/N	KPMI P/N
Installation Protector	09-4592-00	20-20636